



OPERATION

- 1) Familiarize yourself with the woodchipper and its controls.
- 2) Wear safety glasses, or helmet and visor combination, loose fitting gloves, and hearing protection.



- 3) No foreign objects such as stones, steel, cans, glass, sweepings, wire, rope or nails should be fed into the chipper chute, as damage will occur.

- 4)  Open fuel shut-off valve, if engine is equipped. Move choke control to CHOKE or START position. Note: Choke must fully close. Move throttle control to RUN or FAST position.




- If engine is equipped with rocker style stop switch, push RUN or I (I = Ignition) before starting. Rewind Starter: Grasp rope handle and pull slowly until resistance is felt to prevent kickback. Then pull cord rapidly to overcome compression and start engine. Repeat if necessary with choke off and throttle control in FAST position. Operate engine in FAST position.

- 5) Allow engine to reach full R.P.M. and operating temperature. Start all cuts at top speed-full throttle and continue to cut at top speed full throttle.

- 6) When feeding branches into chipper, make sure to feed the large end of the branch first. Place the branches into the material intake hopper from the operator zone. Branches should not be forced into the intake hopper. If branches are extremely long it is recommended that they be cut into shorter lengths to achieve best results. Note: Side branches should be lopped off to avoid clogging the intake hopper. Brush should not be forced into the chipping unit. Chipper should feed itself. If unit does not feed itself, the knives may be dull, or setting may be improper.

- 7)  **CAUTION: If chipper discharge clogs with material, or the cutting disc jams, STOP THE ENGINE IMMEDIATELY TO PREVENT CLUTCH DAMAGE.**




Figure 1



- 8) When unit is in operation, approach chipper from the operator zone side. (See Figure 1) **KEEP CLEAR OF DISCHARGE AREA.** Pay close attention to discharge direction.
- 9)  **The chipping disc will take several seconds to stop after engine has been turned off.**
WARNING: Do not go near the chipping disc for any reason during this period.
- 10) **Stop Engine:** Do not move choke control to CHOKE position to stop engine. Backfire or engine damage may occur. Move throttle control to SLOW position, then push rocker switch to 0 (STOP), or turn key to OFF, if equipped.




AFTER USE

- 1)  Turn fuel tap to "OFF" position.
- 2)  Allow machine to cool down.
- 3)  Clean with warm soapy water. Ensure no water enters the carburettor.



SAFETY PRECAUTIONS AND OPERATING INSTRUCTIONS









CT100 CHIPPER



SAFETY PRECAUTIONS FOR CT100 USERS


USE COMMON SENSE AND PLENTY OF IT

-  **DO NOT** allow any person to operate the woodchipper without first reading and understanding the safety precautions and operating instructions. **KNOW THE CONTROLS AND HOW TO STOP THE WOODCHIPPER QUICKLY IN AN EMERGENCY.**
- NEVER** allow children or untrained adults to operate the woodchipper.
- ALWAYS** wear protective clothing when operating the woodchipper. This includes, but is not limited to; safety glasses, loose fitting gloves, steel capped boots and hearing protection. **NEVER** wear loose fitting clothing or jewellery when operating the woodchipper. Keep all clothing away from moving parts. Items could become caught in the machine, resulting in injury.   
- ALWAYS** use woodchipper in a well lighted area.
- ALWAYS** operate woodchipper on level ground only. Keep your work area clear and free of debris. Never attempt to move a woodchipper over uneven or hilly ground without a tow vehicle or adequate help.
- NEVER** operate the Chipper when fatigued. **ALWAYS BE ALERT!** If you get tired while operating the Chipper, take a break. If you have any type of physical or mental condition that may be aggravated by strenuous work, consult with your physician before you operate this equipment. **NEVER** operate the Chipper under the influence of medication, alcohol or drugs.
-  **DO NOT** allow other persons near the woodchipper. It is up to the operator to keep bystanders and animals a minimum of 6 metres (18ft) away from the machine while in operation.

-  **ALWAYS KEEP YOUR HANDS, FEET AND BODY AWAY FROM THE INTAKE HOPPER AND DISCHARGE CHUTE WHEN THE MACHINE IS IN OPERATION OR THE CHIPPER DISC IS TURNING.**
-  **NEVER** operate the unit without the safety guards in place and in working order. Keep the unit well maintained and in good working order
- DO NOT** leave the machine unattended while the engine is running.
- DO NOT** overspeed the engine or alter the governor settings. Excessive speed is dangerous and will shorten engine life.
-  **NEVER** operate the woodchipper in an enclosed area. Engine exhaust contains carbon monoxide, an odourless and tasteless poison.
-  **STOP** the engine and disconnect the spark plug lead(s) and allow engine to cool before inspecting or performing maintenance on the woodchipper.
-  **REFUELLING**
 - * Shut off engine. **DO NOT REFUEL AN ENGINE WHILE OPERATING!**
 - * Allow engine to cool. Minimum 5 minutes.
 - * **USE UNLEADED FUEL ONLY. Use clean, fresh unleaded fuel.**
 - * **Do not mix oil with unleaded fuel.**
 - * Do not over-fill fuel tank. Allow space for fuel expansion.
 - * Do not smoke.
 - * Allow no naked flame or hot material in refuelling area.
 - * Use only approved fuel containers and funnels. Remember, fuel is a potential hazard.





“STAY ALERT – DON’T GET HURT”




OPERATING INSTRUCTIONS

TRANSPORT

- DO NOT** exceed 60kms per hour (45mph) when towing this product.  
- WARNING:** Make sure discharge chute is tightened and secure before towing. (See Figure 1)

BEFORE USE

-  **WARNING:** Before starting engine, inspect the material intake hopper and remove any foreign debris or branches. Perform a thorough visual inspection of the woodchipper and the chipper disc drive system.
- Rotate and set discharge chute to desired direction and angle. Keep directional discharge chute clear of operator zone. (See Figure 1)